

## **Návod k použití mincovního automatu (Interaktivní ovládání - Volba sprchy uživatelem)**

### **SLZA 01LN, 01LNZ, 02LN a 02LNZ**

- Zvolte sprchu, která je volná (svítí zeleně), vhod'te mince/žetony a potvrďte stiskem libovolného tlačítka
- Vodu spouštějte a zastavujte stiskem tlačítka ve sprše do vyčerpání kreditu
- 30 vteřin před koncem sprcha 4x zapulzuje
- Pokud ještě neuplynul čas sprchování a chcete jej prodloužit - zvolte požadovanou sprchu, vhod'te další mince a potvrďte tlačítkem

## **User guide for coin shower control (Interactive control - Choice of the shower by the user)**

### **SLZA 01LN, 01LNZ, 02LN and 02LNZ**

- Select the shower (free/available shower buttons lit green), insert coins/tokens and confirm by pressing of any button
- User can start/stop the water stream until the credit expires
- 30 seconds before the credit expiration the shower notify the user by a 4-pulse sequence
- In case the credit pre-paid time did not run out yet and the user would like to extend the time of showering - select the shower, insert coins/tokens and confirm by pressing the button

## **User guide for coin shower control (Interactive control - Choice of the shower by the user)**

### **SLZA 01LN, 01LNZ, 02LN and 02LNZ**

- Select the shower (free/available shower buttons lit green), insert coins/tokens and confirm by pressing of any button
- User can start/stop the water stream until the credit expires
- 30 seconds before the credit expiration the shower notify the user by a 4-pulse sequence
- In case the credit pre-paid time did not run out yet and the user would like to extend the time of showering - select the shower, insert coins/tokens and confirm by pressing the button

## **Gebrauchsanweisung für Münzautomat (Interaktive Steuerung - Duschauswahl durch Benutzer)**

### **SLZA 01LN, 01LNZ, 02LN und 02LNZ**

- Wählen Sie die Dusche (freie/verfügbare Duschkнопfe leuchten grün), legen Sie Münzen/Jeton ein und bestätigen Sie durch Drücken von eine beliebige Taste
- Der Benutzer kann den Wasserstrom starten/stoppen, bis das Guthaben abläuft
- 30 Sekunden vor Ablauf des Guthabens benachrichtigt die Dusche den Benutzer durch eine 4-Puls-Sequenz
- Falls die im Voraus bezahlte Kreditzeit noch nicht abgelaufen ist und der Benutzer die Duschzeit verlängern möchte - Wählen Sie die Dusche aus, legen Sie Münzen/Jeton ein und bestätigen Sie mit der Taste