

Návod k použití mincovního automatu (Přímé ovládání - Volba sprchy uživatelem)

SLZA 01LM, 01LMZ, 02LM a 02LMZ

- Zvolte sprchu, která je volná (svítí zeleně), vhod'te mince/žetony a potvrďte stiskem libovolného tlačítka
- Nyní máte čas na přesun do zvolené sprchy
- 30 vteřin před koncem sprcha 4x zapulzuje
- Pokud ještě neuplynul čas sprchování a chcete jej prodloužit - zvolte požadovanou sprchu, vhod'te další mince a potvrďte tlačítkem

User guide for coin shower control (Direct control - Choice of the shower by the user)

SLZA 01LM, 01LMZ, 02LM and 02LMZ

- Select the shower (free/available shower buttons lit green), insert coins/tokens and confirm by pressing of any button
- Move to the assigned shower
- 30 seconds before the credit expiration the shower notify the user by a 4-pulse sequence
- In case the credit pre-paid time did not run out yet and user would like to extend the time of showering - select the shower, insert coins/tokens and confirm by pressing the button

User guide for coin shower control (Direct control - Choice of the shower by the user)

SLZA 01LM, 01LMZ, 02LM and 02LMZ

- Select the shower (free/available shower buttons lit green), insert coins/tokens and confirm by pressing of any button
- Move to the assigned shower
- 30 seconds before the credit expiration the shower notify the user by a 4-pulse sequence
- In case the credit pre-paid time did not run out yet and user would like to extend the time of showering - select the shower, insert coins/tokens and confirm by pressing the button

Gebrauchsanweisung für Münzautomat (Direkte Steuerung - Duschauswahl durch Benutzer)

SLZA 01LM, 01LMZ, 02LM und 02LMZ

- Wählen Sie die Dusche (freie/verfügbare Duschtasten leuchten grün), legen Sie Münzen/Jeton ein und bestätigen Sie durch Drücken einer beliebigen Taste
- Geh in die Dusche
- 30 Sekunden vor Ablauf des Guthabens benachrichtigt die Dusche den Benutzer durch eine 4-Puls-Sequenz
- Falls die im Voraus bezahlte Kreditzeit noch nicht abgelaufen ist und der Benutzer die Duschzeit verlängern möchte - Wählen Sie die Dusche aus, legen Sie Münzen/Jeton ein und bestätigen Sie mit der Taste